ifz.co.th

TECHNICAL Data sheet

IPOC ROIP ED-137

APPLICATION

FOR HYTERA P50 PRO





APPLICATION OVERVIEW

iPoC is a RoIP (Radio over IP) application designed to transform the Hytera P50 Pro into a Smart Radio Endpoint. It enables seamless connectivity with a Radio Server or iGate over IP networks, allowing users to transmit/receive audio and manage PTT (Push-to-Talk) operations directly from the device or via a Web Config interface.

SYSTEM INTEGRATION

- Connects to Radio Server / iGate / RoIP Gateway over IP networks.
- Supports configuration for CH1–CH4, with the ability to independently designate a Main Server and Standby Server for each channel.
- System administrators can configure settings via a Web Browser by logging in with an administrator account.
- Operates via LAN or Wi-Fi, using the IP address assigned within the actual production network

ITEM	DESCRIOTION
Application	iPoC RoIP ED-137 Application
Device Model	Hytera P50 Pro
System Role	RoIP endpoint for controlling Radio channels CH1-CH4
Operation Mode	Muti-channel audio reception, selectable transmit channel and PTT activation via device buttons
Configuration	Via Web Browser at the device's IP address, e.g.,http://<device-ip>:8080

FEATURES

- Supports up to 4 independent channels (Channel 1 to Channel 4).
- Allows users to configure channel names, channel colors, enable/disable status, and toggle channel visibility (show/hide) directly from the Web Config interface.
- Supports independent SIP URI configuration for both Main Server and Standby Server on a per-channel basis.
- Displays real-time operation status on the device screen, including STARTED, LINK, MAIN IN USE, STBY OK/OFF, RX ON/OFF, and TX ON/OFF.
- Allows configuration of Local SIP settings, including Local domain/IP, Local user, and PTT level.
- Saved changes can be applied immediately with the ability to restart the application directly via Web Config.
- Supports exporting and importing configuration data as JSON files for backup purposes or easy duplication to other devices

FOR MORE INFORMATION

02-171-7857

contact@ifz.co.th

บริษัท ไอแอฟแซด จำกัด
36/59 ถนนมอเตอร์เวย์ แขวงคลองสองต้นนุ่น ลาดกระบัง กรุงเทพ 10520

ifz.co.th

TECHNICAL Data sheet

IPOC ROIP ED-137

APPLICATION

FOR HYTERA P50 PRO



SUPPORTED STANDARDS AND PROTOCOLS

Protocol	System Role
SIP	Used for signaling and session establishment between iPoC and the Radio Server / iGate.
RTP	Use for transmitting media/audio streams between RoIP endpoints.
ED-137/RoIP Profile	Provides guidelines for transmitting PTT, RX/TX states, and R2S/Radio signaling for Radio over IP operations.
G.711 Audio	Used as the standard default audio codec within the RoIP system according to the specified profile.
IPv4/UDP/ TCP	Used for SIP/RTP connectivity and Web Config services.
HTTP+ WebSocket	Used for the Web Config interface, connection status monitoring, and configuration management.

ON-DEVICE CONTROLS

Number keys 1-4	Used to select or control CH1–CH4 to Enable / Disable TX/RX according to the application logic.
Top Rotary Knob	Used to switch the desired channel to become CH_TX Enable.
Side PTT Button	Press and hold to transmit audio to the selected TX channel.
Top Orange Button	Can also be used as a PTT button.
Topmost side button	Toggles screen On/Off.
VOL+ / VOL-	Increases or decreases the volume level.
Bottom USB Type-C	Used for charging the device's battery.

SPECIAL FEATURES

- Can be controlled via both physical buttons on the device and through a Web Browser.
- Supports multi-channel usage with independent RX and TX tracking per channel.
- Provides real-time Main / Standby status indicators, allowing users to clearly see which destination is currently active.
- Ideal for RoIP, Radio Gateway, Dispatch operations, or any communication system requiring portable endpoints.
- Reduces setup time and complexity in the field by utilizing JSON file backup and configuration import.

FOR MORE INFORMATION

02-171-7857


contact@ifz.co.th

บริษัท ไอแอฟแซด จำกัด
36/59 ถนนมอเตอร์เวย์ แขวงคลองสองต้นนุ่น ลาดกระบัง กรุงเทพ 10520

IPOC ROIP ED-137

APPLICATION

FOR HYTERA P50 PRO



WEB CONFIG

The Web Config interface is used to configure connection settings for each channel and the device's Local SIP parameters. It can be accessed via a Web Browser from a computer or any device connected to the same local network.



MENU/FIELD	DISCRIPTION
Login	Access for administrators (e.g., admin/password) ; it is highly recommended to change the password after installation.
CH1-CH4	Configures channel name, color, enable/show channel status, Main Server, and Standby Server.
Main/Standby Server	Defines the User, IP/Host, and Port for the SIP Server.
Local SIP	Defines the Local domain/IP, Local user, and PTT level.
Save to iPoC+ Restart	Saves settings to the device and restarts the application to apply the new configuration.
Save Config to PC	Downloads and saves the configuration file as a backup.
Import Config JSON	Restores an existing configuration or imports settings to configure another device.

BASIC OPERATING REQUIREMENTS

Network	The iPoC device and the Radio Server must be on a routable network.
IP Address	It is recommended to assign static IP addresses to both the device and the Server.
Firewall	Open SIP/RTP ports according to each channel's configuration, such as ports 5060–5063 and the system-specified RTP ports.
Power	Charge via USB Type-C and verify the battery status prior to field deployment.
Operation	Before pressing PTT, ensure that TX ON is enabled on the intended transmission channel.

FOR MORE INFORMATION

02-171-7857

contact@ifz.co.th

บริษัท ไอแอฟแซด จำกัด
36/59 ถนนมอเตอร์เวย์ แขวงคลองสองต้นนุ่น ลาดกระบัง กรุงเทพ 10520